

# PENTEK® WPX-BB SERIES

## POLYPROPYLENE STRING-WOUND CARTRIDGES

DESIGNED FOR A VARIETY OF APPLICATIONS REQUIRING SEDIMENT REDUCTION



Pentair® Pentek® WPX-BB Series Cartridges are manufactured in 10" and 20" lengths and in 4.5" diameters from a durable polypropylene cord that is wound around a rigid polypropylene core. The WPX-BB Cartridges are an economical solution to reduce fine sediment including rust, sand and scale particles.

The material in the WPX-BB Cartridges is a fibrillated polypropylene media wound in a precise pattern around a polypropylene core, providing greater surface area to maintaining high flow rates. The WPX-BB Cartridges are manufactured without any anti-static agent.

These string-wound cartridges are capable of withstanding temperatures up to 165°F (73.9°C), and will accommodate flow rates between 10 and 65 GPM with minimal pressure drop.

WPX-BB Series Cartridges are suitable for a wide range of sediment applications including municipal and well water, and are bacteria and chemical resistant so they can be used with many industrial fluids. WPX-BB Cartridges are recommended when foaming is an application issue.

### FEATURES/BENEFITS

String-wound design reduces fine sediment from a variety of fluids

Bacteria and chemical resistant

Economically priced

Nominal 5, 10, 25, 50, 100 micron rating

Lengths: 10", 20"

### SPECIFICATIONS

Filter Media – fibrillated polypropylene fiber cord

Temperature Rating – 40-165°F (4.4-73.9°C)

## SPECIFICATIONS AND PERFORMANCE

MODEL #	PART #	MAXIMUM DIMENSIONS	RATING (NOMINAL)*	INITIAL ΔP (PSI) @ FLOW RATE (GPM)*
WPX5BB97P	355217-43	4.5" x 9.88" (114 mm x 251 mm)	5 micron	<16 psi @ 10 gpm (<1.1 bar @ 38 Lpm)
WPX10BB97P	355218-43	4.5" x 9.88" (114 mm x 251 mm)	10 micron	<12 psi @ 15 gpm (<0.8 bar @ 57 Lpm)
WPX25BB97P	355219-43	4.5" x 9.88" (114 mm x 251 mm)	25 micron	<10 psi @ 20 gpm (<0.7 bar @ 76 Lpm)
WPX50BB97P	355220-43	4.5" x 9.88" (114 mm x 251 mm)	50 micron	<8 psi @ 30 gpm (<0.6 bar @ 114 Lpm)
WPX100BB97P	355221-43	4.5" x 9.88" (114 mm x 251 mm)	100 micron	<8 psi @ 40 gpm (<0.6 bar @ 151 Lpm)
WPX100BB20P	355226-43	4.5" x 20" (114 mm x 508 mm)	100 micron	<8 psi @ 65 gpm (<0.6 bar @ 246 Lpm)

\*Based on manufacturer's internal testing.

**WARNING:** Do not use where water is microbiologically unsafe or with water of unknown quality without adequate disinfection before or after the system.



### FILTRATION & PROCESS

5730 NORTH GLEN PARK ROAD, MILWAUKEE, WI 53209  
 P: 262.238.4400 | F: 262.238.4404 | WWW.PENTAIRAQUA.COM | CUSTOMER CARE: 800.279.9404

All Pentair trademarks and logos are owned by Pentair, Inc. or its affiliates. All other registered and unregistered trademarks and logos are the property of their respective owners. Because we are continuously improving our products and services, Pentair reserves the right to change specifications without prior notice. Pentair is an equal opportunity employer.

247670 REV B MR14 © 2014 Pentair Residential Filtration, LLC. All Rights Reserved.